




**WPM**  
WELHOME PRO

**GRINDER PARTS**

- Handle with stainless steel ball bearing  
Smooth rolling and anti-drop
- All-in-one body  
Middle shaft with double ball bearing
- 38mm stainless steel burrs
- Whole body disassembly possible
- Travel-friendly

- Walnut handle
- Stainless steel lever
- Double ball bearing
- Body
- Funnel
- Burr ring
- Double ball bearing
- 38mm stainless steel grinding burrs
- Grinding regulator
- Metallic powder receiver

**MC-MG38sII**

**AIRFLOW**

Product & packaging are subject to actual product.  
Specifications, accessories and design are subject to change  
without prior notice. Please keep this user manual for future  
reference.


Thanks for buying our product and best wishes to you.

**CAUTIONS**

- This device is designed only for coffee bean grinding.
- Please do not disassembly the precision grinding regulator.
- Please get children out of reach of this device to avoid any hurt.
- Please beware of sharp burr edge to avoid scratching.
- Replacement of burrs and exchange of any internal parts by users are not recommended.
- Please inquire our technical staff first for any exceptional usage.


⚠ Our company is not responsible for any consequences derived from not observing the above cautions.

# HOW TO USE




- Release the receiver by turning leftward. Turning the regulator to obtain the required fineness.

Install handle assembly, hold down the body and handle. Press down and turn the grinding regulator. Turn clockwise for a finer grind, and counter-clockwise for coarse. (if there is a strain, first turn counter-clockwise with 2 clicks then turn clockwise again)




- Remove the cover with lever handle by taking out vertically up. Put roasted beans in (not more than 20g per time) .




- Put back the cover (as picture). Hold the body by one hand and grip the handle by another to rotate the lever clockwise to proceed grinding. After grinding, release the bottom receiver by turning leftward to pour the powder out.

⚠ Fingers should not exceed the height of regulator ring to avoid scratching.



- After pouring out the coffee powder, please use the brush given for cleaning.

# ADJUSTING THE GRIND SETTING



Turn the regulator to adjust the fineness (Turn clockwise for a finer grind, and counter-clockwise for coarse.)

⚠ Do not force to rotate over the origin that will damage the burrs.

|              |                                      |
|--------------|--------------------------------------|
| Espresso     | 5 ~ 10 clicks ( 0.3 ~ 0.8 rotation ) |
| Pour-over    | 16 ~ 30 clicks ( 1 ~ 2 rotation )    |
| French Press | 30 ~ 40 clicks ( 2 ~ 2.5 rotation )  |

16 clicks per rotation

Due to different roasted levels of beans and personal taste, grinding fineness requirements may also be different. The above are for reference only.

# DAILY CARE

It is advised to use the brush given for cleaning. Washing by water is viable but do not submerge it into water or wash it for too long time.

(Long period washing will shorten the life of the shaft)

Use only water at normal temperature to clean. After wiping by dry cloth, put it under the sun for better drying. Then, always store it at a dry place.

G.M.P. Industrial Co Ltd  
Address: 7/F, Meyer Industrial Building, 2 Chong Yip Street, Kwun Tong, Kowloon, Hong Kong  
Tel. No.: +852 23438211  
Fax: +852-23431647  
E-mail:welhome@gewcorp.com  
Website :www.wpm.hk